



**Part number IS1400
90-93 Acura Integra (NO ABS)**

Contents Included:

- 1 Injen Intake system
- 1 3" Injen Filter w/Clamp (1014)
- 1 2.75" Step Hose (3011)
- 1 12"- 4mm vacuum hose (3104)
(90-91 models)
- 1 11"- 10mm vacuum hose (3077)
- 1 4mm plastic T Fitting (8006)
- 1 1/4" coupler (8008)
- 1 Power-band (.362).048 (4004)
- 1 Power-band (.312) (4003)
- 1 m6 vibra-mount (6020)
- 2 m6 flange nut (6002)
- 1 Fender washer (6010)
- 1 License Plate Frame (9010)
- 1 Instruction

Note: All parts and accessories are now available on-line at: www.injenonline.com

Congratulations! You have just purchased the best engineered, dyno-proven intake system available.

Please check the contents of this box immediately.

Report any defective or missing parts to the Authorized Injen Technology dealer you purchased this product from.

Before installing any parts of this system, please read the instructions thoroughly. If you have any questions regarding installation please contact the dealer you purchased this product from.

Installation DOES require some mechanical skills. A qualified mechanic is always recommended.

*Do not attempt to install the intake system while the engine is hot. The installation may require removal of radiator fluid line that may be hot.

Injen Technology offers a limited lifetime warranty to the original purchaser against defects in materials and workmanship. Warranty claims must be handled through the dealer from which the item was purchased.

Injen Technology 285 Pioneer Place Pomona, CA 91768 USA

Please check the contents of this application before installing.










Figure 1

**Now Available, Hydro Shield by Injen
Part Number X-1033**



Hydro Shield Sold Separately





Cold air extension sold separately: 3" straight hose, extension w/bracket, vibra-mount and m6 nut
Note: Disconnect the negative battery terminal before starting this installation.

1. Remove the air intake box and the air intake duct leading to the throttle body.
2. **Note: The car must be completely cold before removing any lines for this step.**
Remove the PCV pipe connecting the breather hose and waterbypass hose. (See fig. 2) Reconnect the water bypass coolant hose by using the 1/4" coupling to join the two lines, use the stock clamps to secure lines. (Fig. 3)
3. Attach the 2 3/4" end of the step hose onto the throttle body and use two clamps, tighten the clamp on the throttle body at this point. (See fig. 3)
- 4 Remove the harness plug from the fender wall brace. (See fig. 4)
5. Take the vibra-mount and m6 nut and insert one end into the hole in the brace use the m6 nut to fasten the vibra-mount in place. (See figs. 5 and 6)
6. Insert the nipple end of the Injen intake into the 3" side of the step hose and align the bracket to the vibra-mount stud. (See fig. 7) Use the m6 nut and washer on the vibra-mount to hold the intake and semi-tighten the clamp.
7. Connect the stock fast start solenoid vacuum hose with the one way check valve to the 3/16" nipple on the intake. Connect the 11"-10mm breather hose to the port on the valve cover and the 1/2" nipple on the intake. (See fig. 8)
For all 90-91 models only- Splice the fast start solenoid hose and use the T- fitting supplied to reconnect the line to the 3/16" nipple. (See fig. 9) Take the 12"- 3mm hose and connect it to the T-fitting the other end will loop over to the cold start solenoid port as seen in figure 9.
8. Press the 3" Injen filter on the end of the intake system and tighten the clamp on the filter. (See figs. 1 and 10)
9. Align the entire intake for best fit making sure there is no rubbing anywhere along the length of the intake. Continue to tighten all nuts, bolts and clamps and reconnect the negative battery terminal. (See fig. 1)
10. Remove all tools and rags from the engine compartment before starting the engine.
11. Congratulations! You have just completed the installation.

Injen technology now sells spark plug covers and oil caps for this application. Inquire at your local dealer or call Injen Technology for details.

